

Table D.4 — Conversion between various Vickers hardness scales for high speed steels of steel grades X80WMo6.5, X82WMo6.5, X90WMo6.5, X97WMo3.3, X100WMo6.5, X85WMoCo6.5.5 and X105WMoCo6.5.5

高速钢（钢号详见英文标题）的不同维氏硬度单位换算值

HV	HV 10	HV 5	HV	HV 10	HV 5
580	587	589	750	760	762
590	598	599			
600	608	609	760	770	772
			770	780	782
610	618	620	780	790	792
620	628	630	790	801	802
630	638	640	800	811	813
640	648	650	810	821	823
650	658	660	820	831	833
			830	841	843
660	669	670	840	851	853
670	679	681	850	862	863
680	689	691			
690	699	701	860	872	874
700	709	711	870	882	884
			880	892	894
710	719	721	890	902	904
720	730	731	900	912	914
730	740	742	910	923	924
740	750	752	920	933	935

NOTE If only HV is given without a number, then most probably HV30 is meant.